


STEP 1:

Transfer half of the desired cream into the applicator in several steps using a spatula, ointment jar, or filling system. **Cover all of the bottom of the barrel**, being sure to fill the corners. To remove air, **tap the bottom** of the applicator on your palm or a countertop as you go.


STEP 2:

Add the drug to the barrel.
***NOTE:** Do not allow liquid drug to flow past the cream surface to the bottom of the barrel.*


STEP 3:

Add the rest of the cream to the barrel while removing all air.
***NOTE:** Cover the drug completely with cream. Do not allow liquid drug to flow to the top of the cream.*


STEP 4:

Attach the disposable mixing paddle to the electronic mortar and pestle shaft and insert the shaft into the mixing cap.
***NOTE:** A standard reusable mixing blade may also be used.*


STEP 5:

Insert the mixing paddle into the barrel and **plunge it to the bottom**. Then, while holding the barrel **screw the mixing cap** onto the barrel.


STEP 6:

Program and prepare the electronic mortar and pestle machine, then attach the UnoDose™ applicator to it. **Start** the mixing cycle.
***NOTE:** Observe the mixing paddle through the wall to confirm complete mixing, top to bottom, of the barrel contents.*


STEP 7:

When the cycle completes, **remove the applicator** and **unscrew the cap**.


STEP 8:

Wipe the mixing paddle blades on the rim of the barrel, if needed, to transfer any cream remaining on the blades into the applicator. **Remove and discard the paddle**.
***NOTE:** The cream should show signs of proper mixing action.*