



MEDISCA[®]
YOUR TRUSTED PARTNER IN COMPOUNDING

PRODUCT NO.: 6456



WALL MOUNTED EMERGENCY EYEWASH (STAINLESS STEEL BOWL)

DESCRIPTION: This eyewash station provides a high level of performance. It has a dual aerated spray head with automatic flow control and flip top dust covers. The aerated water flow allows soft flowing water to provide a wider coverage, cleaning full facial areas. The eyewash station is equipped with a stay-open ball valve activated by a paddle handle allowing hands-free operation once the eyewash has been activated.

FEATURES:

- ▣ Two aerated yellow plastic spray outlets
- ▣ 300 series stainless steel bowl
- ▣ 1/2-inch NPT female brass, chrome-plated valve
- ▣ Stainless steel push handle activator
- ▣ 1/2-inch NPT female inlet
- ▣ 3.18 gpm at 30 psi
- ▣ Universal emergency sign included
- ▣ ANSI/ISEA Z358.1 compliant

WARRANTY: 3 years