



**MEDISCA**<sup>®</sup>  
YOUR TRUSTED PARTNER IN COMPOUNDING




**PRODUCT NO.: 6458**



## AIR CURRENT INDICATOR

**DESCRIPTION:** This device produces a harmless cloud of smoke that floats freely and easily, because it has the same density as ambient air. Consequently, slight air current become visible to easily identify leaks and test the integrity of air-tight systems.

### FEATURES:

-  Better room temperature and air quality
-  Harmless smoke
-  Easy to use

### TECHNICAL SPECIFICATIONS:

Dimensions, W x D x H (mm)	~300 x 200 x 70
Weight (g)	~500
Operating Temperature	5 °C to 40 °C
Smoke Time per Ampoule	~3 minutes
Operating Time per Battery Charge	~20 minutes
Ni-Cd rechargeable Battery	7.2 V; 1.4 Ah
Charging current (mA)	700

**WARRANTY:** 1 year