



**MEDISCA**<sup>®</sup>  
YOUR TRUSTED PARTNER IN COMPOUNDING

**PRODUCT NO.: 7767**



**CALIBRATION WEIGHT, TROEMNER (50 g)**  
Stainless Steel, Class F w/Traceable Certification

**DESCRIPTION:** This stainless steel weight is primarily used to test commercial weighing devices by state and local weights and measures officials, device installers, and service technician. It meets specifications as outlined in NIST Handbook 105-1 and is approved to be used on legal for trade devices within the United States.

This weight can be used to test most accuracy Class III scales, all scales of Class III L or III I, and scales not marked with a class designation. It can also be used in verifying scales that have 0.1% accuracy or lower.

**TECHNICAL SPECIFICATIONS:**

Weight (g)	50
Dimensions, Ø × H (in)	0.735 × 0.9
Class	Class F
Tolerance (mg)	10
Material	303 Stainless Steel
Density at 20°C (g/cm <sup>3</sup> )	7.85