



MEDISCA[®]
YOUR TRUSTED PARTNER IN COMPOUNDING

PRODUCT NO. 8303



IMPULSE BAG HEAT SEALER W/CUTTER (MIDWEST PACIFIC)

16" Seal Length, 6mil Maximum Sealable Material Thickness

DESCRIPTION: Adjustable electronic timer controls heating duration to properly seal polypropylene and polyethylene bags up to 6 mil thick. No warm-up required. Flat element sealer with cutting blade creates super strong, tamper-evident seals. Just press down armature to seal, then slide the built-in cutting blade to trim. Blade cuts within 1/4" of seal and a short tail flap remains. Flat element sealer does not melt through bags. Not recommended for sealing material thicker than 6 mil. 16" seal width.

TECHNICAL SPECIFICATION:

-  Seal width: 16"
-  Maximum Sealable Material Thickness: 6 mil

ADDITIONAL INFORMATION:

WARRANTY: 90 days