



MEDISCA[®]
YOUR TRUSTED PARTNER IN COMPOUNDING

PRODUCT NO.: 8868












WIPE, ALPHASAT (4" × 4", ISO Class 4-9)
Pre-Wetted w/70% IPA

DESCRIPTION: Cleanroom laundered and packaged, the AlphaWipe is an ultraclean and highly sorbent wiper ideal for critical environments. This wipe is constructed from 100% continuous-filament polyester in a double-knit, no run interlock pattern. It exhibits low particle and fiber levels and has a laundered cut edge.

Can be used in the following applications: (1) General wiping (2) Spill control (3) Cleaning and polishing stainless steel (4) Large surface areas (5) Protective covering for parts and products (6) ISO Class 4-5 (7) ISO 6-9

FEATURES:

-  100% polyester fiber – continuous-filament, double-knit
-  Cleanroom laundered and packaged
-  Solvent-safe packaging
-  Lot-to-lot traceability
-  Ultra low levels of particles and extractables
 -  Continuous filament fibers prevent shedding
 -  Prevents cleanroom contamination
-  Resists abrasion with rigorous to use or rough surfaces
-  Excellent chemical resistance

TECHNICAL SPECIFICATIONS:

| | |
|----------------------------------------|-----|
| Basis Weight (g/m ²) | 158 |
| Sorptive capacity (mL/m ²) | 530 |
| Sorptive rate (s) | 0.5 |